



# in.k120

Auxiliary keypad for your spa



The Quick Reference Card provides a quick overview of your spa's main functions and the operations accessible with your digital control pad.

## Spa functions



### Pump 1 key

Press **Pump 1** key to turn pump 1 on at low speed. Press a second time to turn pump to high speed (with a dual-speed pump). A third time turns pump off. A built-in timer automatically turns pump off after 20 minutes\*, unless pump has been manually deactivated first.



### Pump 2 key

Press **Pump 2** key to turn pump 2 on at low speed. Press a second time to turn pump to high speed (with a dual-speed pump). A third time turns pump off. A built-in timer automatically turns pump off after 20 minutes\*, unless pump has been manually deactivated first.



### Pump 3/blower key

Press **Pump 3/blower** key to turn pump 3/blower on. Press a second time to turn pump off. A built-in timer automatically turns pump off after 20 minutes\*, unless pump has been manually deactivated first.



### Light key

Press **Light** key to turn light on at high intensity. Pressing a second and a third time reduces light intensity. A fourth time turns light off. A built-in timer automatically turns light off after 2 hours, unless it has been manually deactivated first.

\*Factory default